

PELCO® NW/KF Ball Valves

**92398-16, 92398-25, 92399-16, 92399-25, 92397-16,
92397-25**

PELCO® NW/KF Ball Valves are manufactured with a nickel plated brass body and a highly polished 304 stainless steel ball which seals against a Nitrile rubber seal. Pelco® Ball Valves are intended for operation in clean vacuum lines. Foreign particles can potentially damage or scratch the surface of the ball which compromises the seal causing leaks and valve failure. All valves are thoroughly inspected for scratches and are leak tested at time of assembly. It is the responsibility of the customer to ensure that no particles enter the valve. Damage and/or leaks caused by foreign particles are not covered by the warranty.